

# TENGAISVR

## SMART VIBE RING

# USER MANUAL

#### Always read User Manual before use and store this manual without disposing.






- Press & Hold to turn ON / OFF
- Press Button to cycle through modes
- ●5 vibration strengths (V1~5) & 2 rhythm modes (R1, R2)


ports are wet there is danger of electrocution or death, and damage to product.

The SVR uses a soft silicone, but tightness of the item is subjective to the user. If you feel the product is too tight, or see any adverse bodily effects, cease use immediately and consult a medical professional. The silicone material will stretch due to wear-and-tear from normal, multiple uses. If you feel the Ring is too loose for normal use, please dispose and consider purchasing a new SVR.





- 3 If connected properly, the Charging Lamp will turn on,
- Once fully charged, the Charging Lamp will turn off.
- ⑤ Remove the USB Charger horizontally so as not to damage either the USB Charger or USB port of your charging device



Please ensure USB is compatible with your AC Wall Plug Adapter.

- ⚠ For first use, or use after a long period of disuse, please make sure to fully charge.
- ⚠ To sustain battery life as long as possible, please recharge to full charge at least every 6 months.
- The included USB Cable is not waterproof.
- $\Delta$  Do not attempt to attach or remove USB Cable with wet hands, as this may lead to burns, electrocution, or injury.

#### Instructions

- Do not place Product in mouth. Do not attempt to swallow product. Do not insert item in body.

  Do not use with Massage Olls, Baby Oll, or any oil-based lubricant,

  Use only water-based lubricants with this product,

  The SVR is waterproof up to 50cm. Do not place in deeper waters or expose to intense streams of water. This may lead to product damage.

#### Cleaning & Storage

- Always wash before first use and after every use with cold or tepid water.

  Do not boil or attempt to wash with hot water. Do not place in hot or cold water for extended periods of time.

  If using soap, please use only a mild, neutral soap.
  Dry with a lotch and allow the item to air dry in a cool, dry place. Store in the Travel Case for storage.
  Do not clean with alcohol or highly acidic/alkaline cleaners. This may cause disfiguration of product.
  Store away from direct surlight, in a cool, dry place.
  Please do not store with insecticides, solvents, silicone items, or oil-based products. This may cause the product to become deformed.

- Regarding disposal of Waste Electrical and Electronic Equipment (WEEE).
  The symbol of a crossed-out dustbin indicates that this item should be taken to an appropriate collection point for proper disposal. Please do not dispose with household waste. Product contains Li-ion Polymer Battery.



#### **Troubleshooting**

- ? The product won't turn on / the product won't stay on / the vibration is weak

- Press and hold Button for ?-3 seconds,
  Is the USB Charger still attached to the item? The item will not turn on while charging.

  Ensure the item is fully charged.

  Objecte the battery completely once, then fully charge. There are cases where doing so several times will fix the problem.
  If a long time has passed since purchase, the product life of the battery may have ceased.

## ? The product won't charge / Charging Lamp won't turn on

- Phase ensure cables are connected facing the right direction.

  Phase ensure cables are connected to all plugs and ports, fully,

  Phase ensure cables are connected to all plugs and ports, facing the right direction.

  Phase ensure the USB Charger is connected to all ports, facing the right direction.

  Is there any dirt on the connectors of the cables? If there is, please clean with a dry cloth or cotton swab.

  The Product may be fully charged. The Charging Lamp will turn off once fully charged. Product will not charge if your PC/laptop is not ON.

## ? The product won't stop charging

- ●Please ensure the USB Charger is connected to all ports, facing the right direction.

  ●Is there any dirt on the connectors of the cables? If there is, please dean with a dry cloth or cotton swab.

  ●If the Charging Lamp does not run of after 120 minutes, there may be an issue with the connection.

  Please disconnect completely, reconnect and attempt the charging process once again.

- Caution

  The SVFI uses a soft silicone, but tightness of the item is subjective to the user. If you feel the product is too tight, or see any adverse bodily effects, cease use immediately and consult a medical professional.

  Do not excessively stretch the outer silicone layer. This may cause enapping or other product damage.

  Do not remove the outer allicone layer. This may cause product damage or other defects and is a fire hazard.

  Do not attempt to fix the product if found defective. This may lead to fire and electricity hazards and may put you in danger.

  If you have a pacemaker or other electronic medical instrument, are pregnant, are being treated for any medical issue, or otherwise have any oconcern regarding your health, please consult a doctor befrove use of this product.

  DO NOT use on any damaged, irritated skin or any other bodily areas requiring medical attention.

  If you notice any adverse physical effects during use, cease use immediately and contact a medical professional. Prelonged use may cause injury or health problems and the product OFF. Continued use may cause injury.

  Wheep out of reach of children Detachable parts may cause choking hazards.

  Do not place item in or near open flames. Do not attempt to heat the item up or place in high temperature areas. Do not use if hot. Any of these may lead to overheating, fire hazards or explosion of item.

  Always connect USB Cable to Charging Port fating the correct way up. Not doing so may lead to damage of product, overheating, or fire hazards.

- ●Do not use if USB Cable or Connectors are damaged or loose. Continued use may cause short circuiting or electric and fire
- hazards.

  On ortuse if USB Cable is damaged. This may lead to short-circuiting of item, electrocution, or fire hazards.

  The included USB Cable is not waterproof.

  Do not touch USB Cable with wet hands. This may cause electric or fire hazards.

  ALWAYS ensure the ports are dry after washing. If ports are wet there is danger of electrocution or death, and damage to product.

## Attention

- Always wash before and after every use.

  Do not boil or attempt to wash with hot water. Do not place in hot or cold water for extended periods of time.

  Do not clean with alcohol or highly acidic/alkalme cleaners. This may cause disfiguration of product.

  Store away from direct sulight, in a cool, dry place.

  Please do not store with insecticides, solvents, silicone items, or oil-based products. This may cause the product to become
- Please ensure USB is compatible with your AC Wall Plug Adapter.
- For first use, or use after a long period of disuse, please make sure to fully charge.
  To sustain battery life as long as possible, please recharge to full charge at least every 6 months.
  Always remove USB Cable when cleaning item.
  DO NOT drop or expose to extreme force as this may cause product damage.
- to not place Product in mouth. Do not attempt to swallow product, I ●Do not use when tired or under the influence of alcohol as this may cause health troubles
- Do not use in salt water or sea water. This may lead to product damage.
  Do not share with others to avoid transmission of contagious diseases and infections.
- Do not use on same part of body for over 15 minutes.

  Always turn OFF after use to avoid physical accidents or product damage.

  Always connect USB Charger facing the correct direction to avoid possible damage or fire hazards.
- DO NOT pull cable to unplug from electricity outlet. Pull from the connectors of the cable.
   Pulling from the cable may damage the cable, and may cause electricity hazards, short circuiting, fire hazards, and product
- Do not charge the product while ON. This may cause product damage and fire hazards
- Do not twist/bend or forcibly remove USB Charger. Do not place under heavy objects or near hot objects. These may cause electrical and fire hazards.
   While not charging, always remove USB charger from electricity source to avoid dust or other dirt from causing fire and
- Please occasionally remove dust from USB Plug and USB Charger, as excessive build-up of dust in these areas may cause a

## Product Warranty

- This product is covered by a 6 (six) Month Warranty from date of purchase.

  Product warranty will become void under the following circumstances.

  If you fail to show both this User Manual and Original Purchase Recept.

  Abnormal usage methods, or usage methods denored inappropriate or otherwise mentioned as invalidating Warranty in this User Manual.

  Damages made during delivery of product, moving of product or accidental damages.

  Damages caused by natural diseasters or use at wrong voltage.

  Cosmetic damage due to fair use of Product.

Product Warranty		
Name		
Address		
Telephone Number		
Warranty Period 6 Months		
Date of Purchase		
Place of Purchase (Name of Store, Address, Telephone Number) Attach Receipt		

## Product Specifications

Froduct specifications		
Product Name and Code	SVR(SMART VIBE RING)·BLACK/TSV-001 · PEARL WHITE/TSV-002 · CARMINE/TSV-003	
Running Time / Charging Time	Approx. 60min (at full power) / Approx. 60min (at 5V 1000mA)	
Product Dimensions / Weight	Approx. 90×38×16mm (H×W×D) / Approx. 25g *USB Cable Length: 90cm	
Contents	SVR Product, USB Cable Travel Case, User Manual	
Materials	Product: Silicone, ABS, Li-ion Polymer Battery. Travel Case: PP USB Cable: PVC	

## Manufactured by TENGA Co., Ltd.

1-7-1 Mita, Minato, Tokyo 108-0073, JAPAN

TENGA Europe GmbH - Immermannstr. 15. 40210 Düsseldorf, GERMANY For more information, please visit: tenga.co

Designed by TENGA, Tokyo MADE IN CHINA Registered Design